
Jorge Beltrán de la Cita, Arturo de la Escalera
Perception Systems
Course 2019-2020


Scale Amplitude



Original image




Original histogram



Scale amplitude

Scale Amplitude





New image with scale amplitude

New histogram

Exercise 1: amplitude of a histogram

- Load a grayscale image
- Compute the histogram of the image
- Print the values of the histogram
- Get the maximum and minimum values of the histogram
- Plot the original image and the histogram
- Free memory

Exercise 1: amplitude of a histogram

minMaxLoc

Finds the global minimum and maximum in an array.

C++: void minMaxLoc(InputArray src, double* minVal, double* maxVal=0, Point* minLoc=0, Point* maxLoc=0, InputArray mask=noArray())

C++: void minMaxLoc(const SparseMat& a, double* minVal, double* maxVal, int* minIdx=0, int* maxIdx=0)

Python: cv2.minMaxLoc(src[, mask]) → minVal, maxVal, minLoc, maxLoc

C: void cvMinMaxLoc(const CvArr* arr, double* min val, double* max val, CvPoint* min loc=NULL, CvPoint* max loc=NULL, const CvArr* mask=NULL)

Python: cv.MinMaxLoc(arr, mask=None)-> (minVal, maxVal, minLoc, maxLoc)

- Parameters: src input single-channel array.
 - minVal pointer to the returned minimum value; NULL is used if not required.
 - maxVal pointer to the returned maximum value; NULL is used if not required.
 - minLoc pointer to the returned minimum location (in 2D case); NULL is used if not required.
 - maxLoc pointer to the returned maximum location (in 2D case); NULL is used if not required.
 - · mask optional mask used to select a sub-array.

The functions minMaxLoc find the minimum and maximum element values and their positions. The extremums are searched across the whole array or, if mask is not an empty array, in the specified array region.

The functions do not work with multi-channel arrays. If you need to find minimum or maximum elements across all the channels, use Mat::reshape() first to reinterpret the array as single-channel. Or you may extract the particular channel using either extractImageCOI(), or mixChannels(), or split().

Exercise 1: amplitude of a histogram

normalize

Normalizes the norm or value range of an array.

C++: void normalize(InputArray src, OutputArray dst, double alpha=1, double beta=0, int norm_type=NORM_L2, int dtype=-1, InputArray mask=noArray())

C++: void normalize(const SparseMat& src, SparseMat& dst, double alpha, int normType)

Python: cv2.normalize(src[, dst[, alpha[, beta[, norm_type[, dtype[, mask]]]]]]) → dst

Parameters: • src - input array.

- dst output array of the same size as src .
- alpha norm value to normalize to or the lower range boundary in case of the range normalization.
- beta upper range boundary in case of the range normalization; it is not used for the norm normalization.
- normType normalization type (see the details below).
- **dtype** when negative, the output array has the same type as src; otherwise, it has the same number of channels as src and the depth =CV_MAT_DEPTH(dtype).
- mask optional operation mask.

The functions normalize scale and shift the input array elements so that

$$\|dst\|_{L_n} = alpha$$


(where p=Inf, 1 or 2) when normType=NORM_INF, NORM_L1, or NORM L2, respectively; or so that


$$\min_{I} \mathtt{dst}(I) = \mathtt{alpha}, \ \max_{I} \mathtt{dst}(I) = \mathtt{beta}$$

when normType=NORM_MINMAX (for dense arrays only). The optional mask specifies a sub-array to be normalized. This means that the norm or min-n-max are calculated over the sub-array, and then this sub-array is modified to be normalized. If you want to only use the mask to calculate the norm or min-max but modify the whole array, you can use norm() and Mat::convertTo().


In case of sparse matrices, only the non-zero values are analyzed and transformed. Because of this, the range transformation for sparse matrices is not allowed since it can shift the zero level.


Exercise 1: amplitude of a histogram





Histogram equalization






Histogram equalization





Histogram

Accumulated Histogram




100

150

200

250

50



2000

1500

Exercise 2. Equalize the histogram of an image

- Load a grayscale image
- Compute the histogram of the image
- Print the values of the histogram
- Equalize the histogram
- Print the values of the equalized histogram
- Plot both histograms
- Plot both the original and the equalized image
- Free memory

Exercise 2. Equalize the histogram of an image

equalizeHist

Equalizes the histogram of a grayscale image.

C++: void equalizeHist(InputArray src, OutputArray dst)

Python: cv2.equalizeHist(src[, dst]) → dst

C: void cvEqualizeHist(const CvArr* src, CvArr* dst)

Parameters: • src – Source 8-bit single channel image.

dst – Destination image of the same size and type as src.

The function equalizes the histogram of the input image using the following algorithm:


- 1. Calculate the histogram H for src.
- 2. Normalize the histogram so that the sum of histogram bins is 255.
- 3. Compute the integral of the histogram:

$$H_i' = \sum_{0 \le i \le i} H(j)$$


4. Transform the image using H' as a look-up table: dst(x,y) = H'(src(x,y))

The algorithm normalizes the brightness and increases the contrast of the image.


Exercise 2. Equalize the histogram of an image







Exercise 2. Equalize the histogram of an image



LUTs. Contrast manipulation. Usual transformations:

Inverse function

$$p = 255 - m$$

$$p = \frac{m^2}{255}$$

Quadratic function

$$p = \frac{m}{255}$$

Cubic function

$$p = \frac{m}{255^2}$$

Square root function

$$p = \sqrt{255m}$$


Cubic root function


$$p = \sqrt[3]{255^2 m}$$

Logaritmic function

$$p = 255 \frac{\ln(1+m)}{\ln(1+255)}$$








Exercise 3. Modifying the contrast, usual transformations

- Load a grayscale image
- Compute the histogram of the image
- Print the values of the histogram
- Define and apply all the common LUT functions
- Compute the histogram of the modified images
- Print the values of the new histograms
- Plot the original and the new histograms
- Plot both the original and the modified images
- Free memory

Exercise 3. Modifying the contrast, usual transformations



Arturo de la Escalera & Jorge Beltrán

Perception Systems

Jorge Beltrán de la Cita, Arturo de la Escalera
Perception Systems
Course 2019-2020